



# Getting Started

Warranty Registration



Activity Tracker (Ver 2)

## STEP 1

**Charge Activity Tracker before pairing it to the app.**



Remove wristband (with holes) from the Activity Tracker.

Note: Removing the band will get easier over time.

## STEP 2

### Use your phone charger to charge the Activity Tracker (charger not included).

To use your phone charger, remove cable from the wall charging unit and insert the activity tracker. Charge for about 5 hours.



Note 1: The white part inside the wall charger needs to be at the bottom. Insert Activity Tracker, display side up.



Note 2: If the Activity Tracker does not charge after 15 seconds, remove Activity Tracker, flip charger around and make sure the white part inside charger is at the bottom. Insert Activity Tracker, display side up.

### STEP 3

Download and install the MyHealthConnected app at [www.zewa.com/app](http://www.zewa.com/app)



**IMPORTANT:** During the install (or when first opening the app), the app will ask several installation questions, accept (say “yes”) to all of them.

## STEP 4

### Create a new user account in the app.

- After opening the app for the first time, create a new user account (Join MyHealth-Connected).
- Fill out all the required information.
- Once completed the app will display the “Dashboard”.

## STEP 5

### Pair Activity Tracker to the MyHealthConnected App.

- In the app “Dashboard”, tap on the 3 lines in the top left corner.
- Select “Measurement Devices” or “Manage Devices”.
- Tap on “Connect” next to “**Activity Tracker (Ver 2)**”. Note: On Apple devices the pairing process will start automatically, on Android devices tap the red “Start” button at the bottom of the app.
- The app will require a 6 digit code which is shown on the Activity Tracker display. Enter this code into the app.

## STEP 6

### Finish the pairing process.

- Once pairing is complete, the app will return to the “Measurement Devices” screen, showing the word “Paired” next to the Activity Tracker (Ver 2).
- Tap on the 3 lines in the top left corner and select “Dashboard”.
- The Activity Tracker is now ready for use.  
Note: A minimum of 200 steps may be required for a data transfer.

**For additional help or to watch a video, visit [www.zewa.com](http://www.zewa.com) (select “Products” - “Activity Tracker”).**

## Warranty Registration

Visit us online to register your product and receive special offers and news from Zewa. For a detailed description of your warranty, please refer to the instruction manual.

Register your warranty online:

[www.zewa.com](http://www.zewa.com)

Zewa Inc.  
12960 Commerce Lakes Dr. # 29  
Fort Myers, FL 33913  
Toll Free: 888-993-3592  
[www.zewa.com](http://www.zewa.com)